

PVS 4207

ASSEMBLY INSTRUCTIONS MONTAGEANLEITUNG INSTRUCTIONS DE MONTAGE ISTRUZIONI PER IL MONTAGGIO INSTRUCCIONES PARA EL MONTAJE

NOTE: 2 People are recommended to assemble this furniture.

- A. STAND the rear CMS® frame (1) upright so that it is resting on the floor.
- B. ALIGN the bottom shelf frame (2) with the screw holes located in the bottom rear CMS frame (1) and attach using the long (4") bolts (7) and the supplied Allen key. DO NOT TIGHTEN FULLY.

- C. ALIGN the middle shelf frame (3) with the screw holes located in the middle rear CMS frame (1) and attach using the long bolts (7). DO NOT TIGHTEN FULLY.

- D. SLIDE the inserts that are located on the edges of the two upright legs (4L and 4R) into the open ends of the bottom shelf frame (2) and the middle shelf frame (3) and attach with the small rounded head bolts (8) using the supplied Allen key.

NOTE: The legs are in the proper position when the angled inserts (14) are at the bottom of the leg and facing forwards as shown in Fig. 2.

- E. GO BACK AND FULLY TIGHTEN ALL BOLTS.

NOTE: MOVE the table to the location that it will occupy in the room when fully assembled and in use, PRIOR to placing the glass shelves.

- F. APPLY the smaller protective glass pads (15) to the bottom frame as shown in Fig. 1, and CAREFULLY place the bottom glass shelf (6) onto the frame. The curved edge of the glass should be facing forward.

NOTE: The bottom glass shelf is not as wide as the other two.

- G. INSERT two plastic suction cups (11) into the holes in the middle shelf frame (3) and push into place. APPLY the smaller protective glass pads (15) to the two upright legs (4L and 4R) as shown in Fig.1. PLACE the larger protective glass pads (10) to the back of the middle shelf frame (3) as shown.

- H. CAREFULLY place the middle glass shelf (12) onto the middle shelf frame and GENTLY push downward to create a seal. The curved edge should be facing forward. NOTE: The middle glass shelf is the deepest of the three shelves.

NOTE: The suction cups are intended to limit the movement of the middle shelf and prevent easy shelf removal. To release the seal, gently pull down on the tabs attached to the suction cups.

- I. APPLY the larger protective glass pads (10) to the top shelf support frame (1) as shown in Fig. 1. PLACE two plastic suction cups (11) into the holes in the top shelf support frame (1) and push into place.

- J. ALIGN the metal plate (13), with the screw hole located in the top rear CMS® frame (1) and attach, from the rear, with one of the small rounded head bolts (8) as shown in Fig. 3, using the supplied Allen key. This metal plate will function as a retainer for the top glass shelf.

- K. CAREFULLY angle the top glass shelf (5) slightly upwards, and slide it into the top shelf support frame (1) as shown in Fig. 4, making sure that the curved edge of the glass is facing forward. CAREFULLY center the top glass shelf (5) over the top shelf support frame (1), then lower it GENTLY, pushing downward to create a seal.

NOTE: The top glass shelf is the narrowest of the three shelves.

IMPORTANT: REMOVE ALL GLASS, TV AND OTHER EQUIPMENT FROM THE FURNITURE PRIOR TO MOVING THE ASSEMBLED UNIT. DO NOT ATTEMPT TO MOVE THE ASSEMBLED FURNITURE AFTER THE GLASS SHELVES HAVE BEEN INSTALLED, AND/OR WHEN THERE IS EQUIPMENT LOCATED ON THE FURNITURE AS THIS MAY CAUSE THE SHELVES TO BECOME UNSECURE AND FALL. MAKE SURE THAT THE FRONT OF THE TV IS POSITIONED A FEW INCHES BACK FROM THE FRONT OF THE TOP GLASS. WHEN IN USE, THIS FURNITURE MUST BE PLACED ON A FLAT AND LEVEL SURFACE.

ALWAYS PLACE THE HEAVIEST EQUIPMENT ON THE BOTTOM SHELF.

